

## Air Gap Method

An air gap is a method of backflow prevention and the most effective means however, an air gap may be easily overcome or bypassed if the gap isn't maintained, therefore negating backflow protection. An acceptable air gap must be twice the supply pipe diameter, but never less than one inch.

A diagram of an approved air gap is below:

