




Appendix K

Examples of Accepted Methods for Drawing Mixing Zones



[Not to Scale]

NOTES:

1. The method used to draw the mixing zone does not change the width of the drainfield used in the nitrate sensitivity analysis.
2. The width of just the primary or the replacement area is used in the calculations. The combined width is not used in the calculations.