

---

**MIDDLE CLARK FORK TRIBUTARIES TMDL PLANNING AREA SAMPLING PROJECT - 2010:  
NUTRIENTS**

---

*Sampling and Analysis Plan*

**Prepared for:**

**MONTANA DEPARTMENT OF ENVIRONMENTAL QUALITY**  
Water Quality Management Section, Water Quality Planning Bureau  
P.O. Box 200901  
Helena, MT 59620-0901

**Approvals**

\_\_\_\_\_  
Jonathan Drygas (Monitoring and Assessment)

\_\_\_\_\_  
Date

\_\_\_\_\_  
Rosie Sada (WQMAS Manager)

\_\_\_\_\_  
Date

\_\_\_\_\_  
Lisa Kusnierz (Watershed Management)

\_\_\_\_\_  
Date

\_\_\_\_\_  
Mindy McCarthy (QA Officer)

\_\_\_\_\_  
Date

## TABLE OF CONTENTS

<b>1.0 Introduction and Background Information.....</b>	<b>2</b>
<b>2.0 Objectives and Design.....</b>	<b>2</b>
2.1 Project Objectives .....	2
2.2 Sampling Timeframe .....	3
<b>3.0 Field Sampling Methods .....</b>	<b>3</b>
3.1 Selection of Sites.....	3
3.2 Physical parameters .....	3
3.2.1 <i>In Situ Measurements</i> .....	3
3.2.2 <i>Flow Measurement</i> .....	3
3.3 Water Sample Collection .....	3
3.3.1 <i>Chemistry Samples</i> .....	3
3.4 Periphyton Samples .....	3
3.5 Benthic chlorophyll a and Ash-Free-Dry Weight .....	4
3.6 Digital Photographs .....	4
<b>4.0 Sample Handling Procedures .....</b>	<b>4</b>
<b>5.0 Laboratory Analytical Measurements.....</b>	<b>5</b>
<b>6.0 Quality Assurance and Quality Control Requirements.....</b>	<b>5</b>
6.1 Instrument Calibration .....	5
<b>7.0 Data Analysis, Record Keeping, and Reporting Requirements .....</b>	<b>5</b>
<b>8.0 Schedule .....</b>	<b>6</b>
<b>9.0 Project Team and Responsibilities .....</b>	<b>6</b>
<b>10.0 References.....</b>	<b>6</b>

## 1.0 Introduction and Background Information

This project is to support TMDL development in the Middle Clark Fork Tributaries TMDL Planning Area (TPA) and 303(d) list assessments. The focus will be on nutrients only. This Sampling and Analysis Plan (SAP) aims to meet requirements for the completion of source assessments and loading estimates for nutrients listed streams in this TPA, and to have enough data to assess the streams based on the proposed nutrient criteria (Suplee and Sada, 2010).

The Middle Clark Fork Tributaries TPA is within Missoula, Mineral and Sanders Counties, Montana. The total extent of this TPA is 1137587 acres, or approximately 1777 square miles, and it comprises part of the Clark Fork River watershed. Waterbodies in this TPA flow through both publicly-owned (United States Forest Service, State of Montana and Bureau of Land Management) and privately-owned land. The streams in the Middle Clark Fork Tributaries TPA are within the 4<sup>th</sup> code HUC 17010204 and 17010213, and they have been assigned a B-1 beneficial use classification (ARM 17.30.623).

The Water Quality Planning Bureau (WQP) of the Montana Department of Environmental Quality (MDEQ) has identified 11 impaired (Category 5) streams within the Middle Clark Fork Tributaries TPA; however only the lower reach of Grant Creek, see Table 1.1, will be sampled in 2010. Table 1.1 shows the waterbody segment to be sampled in 2010 with the pollutants of concern (nutrients) within the Middle Clark Fork Tributaries TPA.

Waterbody Segment Name	Waterbody ID	Pollutant
		Nutrients
Grant Creek	MT76M002_130	Nitrate/Nitrite (Nitrite + Nitrate as N)

## 2.0 Objectives and Design

### 2.1 Project Objectives

The main objective of this project is to provide monitoring and assessment support in synchronization with the TMDL Program's schedule for development of nutrients TMDLs in the Middle Clark Fork Tributaries TPA.

The goals for this project are as follows:

1. Measure physical parameters (temperature, DO, pH, and conductivity) *in situ*.
2. Collect nutrients, chlorophyll-a, and periphyton in the stream listed in Table 1.1.
3. Measure flow during each sampling event throughout the summer to assist in TMDL nutrients load allocations.

## 2.2 Sampling Timeframe

All sampling events for nutrients, chlorophyll-a and periphyton will occur during the “growing season” for the Middle Rockies Level III Ecoregion (July 1 – September 30, 2010) (Suplee and Sada, 2010).

## 3.0 Field Sampling Methods

### 3.1 Selection of Sites

Specific site locations within those streams will be identified using GIS and topographic maps. The selected sites follow the guidelines and definitions found in Suplee and Sada (2010) unless a specific location is to be sampled because a pollutant source was identified. These sites are proposed locations. Changes might be made based on land access or other unforeseen problems. A complete list of the stream segments, sites, and the respective sampling needs at each site can be found in Appendix A.

### 3.2 Physical parameters

#### 3.2.1 *In Situ Measurements*

During low flow sampling events (July – September), a YSI 85 meter will be used to measure temperature, dissolved oxygen, and specific conductance at each sampling site. These measurements will be collected prior to the collection of water samples or other physical disturbances to the water column or substrate. A portable pH meter will be used to measure pH at each site. See details about calibration in Section 6.0.

#### 3.2.2. *Flow Measurement*

Flow will be measured at each sampling site during each sampling event. Flow will be measured using either the quantitative flow meter method or using the semi-quantitative float method when streams are not wadeable (MDEQ 2010).

### 3.3 Water Sample Collection

Water samples will be collected at each site after completing the *in situ* YSI 85 measurements. All water samples from the stream will be placed in new high-density polyethylene (HDPE) bottles. Sample replicates will be randomly taken on 10% of the total samples for each parameter. Trip blanks will be made during each sampling run (“trip”).

#### 3.3.1 *Chemistry Samples*

*Nutrients and TSS:* Summary information is shown in Table 3.1. TP and NO<sub>2+3</sub> will be collected in a 250 ml HDPE bottle. This sample will be preserved with sulfuric acid, and held on ice. TN will be collected in another 250 ml HDPE bottle, no preservative, and held on ice. TSS will be collected in a 500 ml HDPE bottle, no preservative, and held on ice. NOTE THE SHORT HOLDING TIME FOR TSS. Detailed methodology can be found in MDEQ (2010).

#### 3.4 Periphyton Samples

Periphyton samples will be collected only at some sites (Appendix A). The sample will be placed in a 50 ml centrifuge tube and preserved with formalin (see Table 3.1). Detailed methodology can be found in MDEQ (2010).

### 3.5 Benthic chlorophyll *a* and Ash-Free-Dry Weight

Benthic chlorophyll *a* will be collected at 11 transects only at some sites (Appendix A). Samples will be collected either using the template, hoop, or core methods, depending on the dominant substrate and/or algae type present. These samples will be composited in the lab according to the collection method (i.e., hoops, cores, templates). Hoop chlorophyll-*a* samples will be stored in zip-lock bags wrapped in aluminum foil, template samples on filters in Petri dishes and wrapped in foil, and cores in centrifuge tubes wrapped in aluminum foil. All samples will be frozen (MT DEQ 2010) (see Table 3.1). Ash-free dry weight (AFDW) will be calculated from the same samples of chlorophyll *a* (MDEQ 2010).

Analyte	Bottle Size	Container	Preservation	Storage	Holding time
TN	250 ml	HDPE bottle	None	Cool to <6 °C (on ice)	30 days
TP, NO <sub>2</sub> +NO <sub>3</sub>	250 ml	HDPE bottle	Sulfuric acid	Cool to <6 °C (on ice)	28 days
Total Suspended Solids	500 ml	HDPE bottle	None	Cool to <6 °C (on ice)	7 days
Chlorophyll- <i>a</i>	N/A	Ziplock bag (hoop), Petri dish (template), or centrifuge tube (core)	None	Dry ice	45 days
Periphyton (species presence)	50 ml	Centrifuge Tube	Formalin	No ice	NA

### 3.6 Digital Photographs

Digital photographs will be taken at transect F of each site (nutrients only sampling events). On the chlorophyll-*a* and periphyton sampling events, photographs will be taken at each transect (A-K). The objective of the photos is to document visible changes in the stream flora as time passes, and as such photos may be a mix of close-ups and stream panoramas. The photo number will be recorded along with the transect identification.

### 4.0 Sample Handling Procedures

This project follows the WQPB "internal process". Appropriate storage times for water quality samples discussed in Sections 3.3 to 3.6 are shown in Table 3.1 above. Water quality samples will be delivered to Energy Laboratory and periphyton samples will be sent to the Academy of Sciences.

## 5.0 Laboratory Analytical Measurements

<b>TABLE 5.1 Analytical Methods and Required Reporting Values.</b>		
<b>Water Sample – Nutrients</b>		
<b>Analyte</b>	<b>Method</b>	<b>Req. Report Limit (ug/L)</b>
Total Persulfate Nitrogen (TPN)	A 4500-N-C	50
Total Phosphorus as P	EPA 365.1	5
Nitrate-Nitrite as N	EPA 353.2	10
<b>Water Sample - Suspended Solids</b>		
<b>Analyte</b>	<b>Method</b>	<b>Req. Report Limit (ug/L)</b>
TSS	EPA 2540D	4000
<b>Others</b>		
<b>Parameter</b>	<b>Method</b>	<b>Req. Report Limit</b>
Chlorophyll -a	A 10200H	N/A
Ash Free Dry Weight	A 10300 (C5)	N/A

## 6.0 Quality Assurance and Quality Control Requirements

This project will follow the WQPB “internal process”. All QA/QC requirements followed by MT DEQ will be instituted for this project. The QA/QC requirements are described in MT DEQ (2005b).

### 6.1 Instrument Calibration

#### YSI 85 meter

Pre-calibration of the YSI 85 meter will be undertaken in the laboratory. The YSI meter will also be calibrated just prior to measuring dissolved oxygen for site-specific altitude at each site following the instructions indicated in the YSI 85 manual.

#### Hand-held pH meter

The pH meter will be pre-calibrated in the laboratory using the two-point method (pH 4.0 and 7).0 standards, and checked against a 4.0 and 7.0 standard prior to each measurement in the field.

## 7.0 Data Analysis, Record Keeping, and Reporting Requirements

This project will follow the WQPB “internal process”. Site Visit/Chain of Custody forms, field forms digital photos, and lab will be processed by WQPB staff following QA/QC procedures as indicated in section 6.0. The GPS coordinate system datum used will be NAD 1983 State Plane Montana, in decimal degrees, to at least the third decimal.

## **8.0 Schedule**

The Water Quality Monitoring and Assessment staff will sample 1 streams within the Middle Clark Fork Tributaries TPA at 2 proposed sites (Appendix A). The sampling events will begin in July 2010. Data collection should be completed no later than September 30, 2010 (Suplee and Sada, 2010).

## **9.0 Project Team and Responsibilities**

The Water Quality Monitoring and Assessment Section will lead the monitoring component. Rosie Sada will oversee the overall Monitoring and Assessment component. Jonathan Drygas will lead the monitoring project. Steven Reistroffer, Steve Fernandes and/or Katie Makarowski will assist with the field data collection. Lisa Kusnierz (Watershed Management Section) will lead the TMDL component.

## **10.0 References**

MT DEQ (Montana Department of Environmental Quality), 2010. Water Quality Planning Bureau Field Procedures Manual for Water Quality Assessment Monitoring. In progress.

MT DEQ (Montana Department of Environmental Quality), 2010. Ultra-low level mercury Standard Operating Procedure. Draft. Montana Department of Environmental Quality, Water Quality Planning Bureau.

MT DEQ (Montana Department of Environmental Quality), 2005b. Quality Assurance Project Plan (QAPP) Sampling and Water Quality Assessment of Streams and Rivers in Montana, 2005. *Available at:* <http://www.deq.state.mt.us/wqinfo/QAPProgram/WQPBOAP-02.pdf>.

Suplee, M., and R. Sada de Suplee. 2010. Guidance Document: Assessment Methodology for Determining Wadeable Stream Impairment due to Excess Nutrients (Nitrogen and Phosphorus). Draft. Montana Department of Environmental Quality, Water Quality Planning Bureau.

## Appendix A

Middle Clark Fork Tributaries TPA proposed 2010 Sampling Site locations  
and

Proposed number of samples to be collected per parameter per site:

Site No.	Water Body Name	LAT (DD)	LONG (DD)	TSS*	Nutrient	Chla/AFDW**	Periphyton
GRANCRK06	Grant Creek	46.8733	- 114.1005	3	3	1	1
New Site	Grant Creek	46.8911	- 114.0920	3	3	1	1

\*Total Suspended Solids (TSS); \*\* Ash Free Dry Weight (AFDW)